PERFORATION RECONDITIONER SET UGHT

Do you have motion picture shrunk films with missing perforations?

You need to replicate the missing perforations but you want to keep correct distance between the perforations?

HERE IS THE LIGHT SOUTION!



With this "LIGHT" approach and set of tools you will:

- **1** Apply some regular and neutral splicing tape to reproduce the original film border of the damaged side, giving back strength to the film support itself.
- **2** Replicate the perforations on the applied tape, punching it through the provided tool that will align the puncher having the opposite correct perforation as reference.



PERFORATION RECONDITIONER SET

Do you have motion picture shrunk films with missing perforations?

You need to replicate the missing perforations but you want to keep correct distance between the perforations?

HERE IS THE SOUTION!



With this set of tools you will be quickly able to:

- **1** Apply some regular and neutral splicing tape to reproduce the original film border giving back strength to the film support itself.
- **2** Measure the new aged and then reduced perforation distance.
- 3 Replicate the perforations on the applied tape, cloning the new shrunken distance so to keep the same pitch on the whole film length.





